



Dell Latitude D620 CD Drive Replacement

Written By: Ivan



INTRODUCTION

Installing a new cd drive into the D620.

Step 1 — CD Drive



- Press in the tab on the bottom right side of the CD drive

i The tab comes out on its own; there is no need to pull it out manually.

Step 2



- Gently pull the tab to remove the disk tray.

To reassemble your device, follow these instructions in reverse order.

